



Congratulations on your purchase of the Dualit spring balance scales. These are precision professional scales that will give you many years of excellent service.

These scales are not certified for portion control and must not be used for weighing of foodstuffs for general sale to the public.

INSTRUCTIONS

Carefully unpack the scale from the carton and remove all transit packing from underneath the bowl support bars.

With the food bowl in place, the pointer needle should be at 0.0kgs (12 o'clock). If this is not the case, simply turn the small screw beneath the food bowl support to adjust. This adjustment can be made to a maximum of 250g. Do not over adjust the screw.

The scales are now ready for use.

Gently place food into the measuring bowl. Food dropped roughly may unbalance the weighing mechanism.

CLEANING

Before first use, thoroughly, wash the measuring bowl in warm soapy water. It is dishwasher safe.

The exterior of the scales can be wiped over with a damp cloth.

Do not immerse scales in water.

GUARANTEE

The Dualit scales are guaranteed for two years from date of purchase.

In the unlikely event of any problems, please return to your Retailer with proof of purchase.

Dualit Ltd, County Oak Way, Crawley, West Sussex, RH11 7ST
TEL: +44 (0) 1293 652 500 FAX: +44 (0) 1293 652 555
WEBSITE: www.dualit.com E-MAIL: info@dualit.com